







## How to update the firmware on your A1270 device

**Prior to firmware update procedure do not forget to back up your data as ALL DATA stored in the device will be DELETED**

1. While holding **Wrench** button  pressed, actuate the **ON/OFF** button . On the screen appears “Upgrade Mode”.
2. Plug USB Cable to connect your A1270 device to PC. The device shows up in the Windows Explorer tree as a new disk drive.
3. Copy file **A1270\_v4.34\_EXPORT.bin** or newer version to the new disk drive; while copying in progress, the display is blinking. Wait till copying completed, i.e. till display stops blinking.
4. Press **ON/OFF** button  to turn the device **OFF**. Unplug USB cable.
5. While pressing the left  and right  arrow keys under the display, press **ON/OFF** button  to activate **FULL RESET** and turn the device **ON**.  
(This step is necessary only for earlier versions)

Your A1270 device is now fully functional.